Support Duat Summary Guidante	Support	Boat Summary	Guic	lance
-------------------------------	---------	---------------------	------	-------

Support Boat Summary Guidance					
RIB Pre-Launch	RIB Launch & On Water Checks	RIB Recovery			
a) Our aim is to ensure fellow members enjoy their sailing	a) Helm MUST wear "Kill cord", just above their knee	a) Do NOT remove RIB from water until OOD says so b) Request OOD assist with RIB recovery ashore			
in the knowledge that we have provided support cover at advertised times appropriate to the conditions	b) Launch RIB helm only aboard (collect crew at pontoon)				
b) Please check weather forecast before going afloat!	c) Do <u>NOT</u> lift fast idle before start (engine auto choke)	c) Drop off crew at pontoon, who can aid recovery ashore			
c) Which RIB to select for Support Duty:	d) Check engine controls are in neutral to start engine	d) Use RIB Trailer with same number as on RIB bow			
• RIB 1 light wind up to F4/5 / less experienced helm	e) Start engine only once engine foot is in deep water	e) Consider recover RIB by pontoon in severe conditions			
• RIB 2 heavier wind / more experienced helm (ie PB2)	f) Reverse out min 50m offshore to avoid prop damage	f) Take care not to damage prop when close to shore			
d) Lift engine up <u>BEFORE</u> leaving cage (button on console)	g) Check engine fully lowered (button on console)	g) Lift engine up <u>BEFORE</u> recovering RIB (button on console)			
e) Check Paynter secure to Trailor (Do <u>NOT</u> rely on winch)	h) Warm up engine before hard acceleration	h) Secure Paynter to Trailor (Do NOT rely on winch)			
f) Inflate sponsons with foot pump until firm / hard	i) Check forward & reverse gears engage OK	i) Once ashore:			
g) Collect RIB keys / VHF / 1 st Aid from Race Hut	j) Check steering turns port & starboard OK	 Remove bung in transom to allow water to drain out 			
h) Collect fuel tank from main fuel store (fill min ¾ full)	k) Check engine Tell Tale for water flow (starboard side)	 Return keys / VHF / 1st Aid to Race Hut 			
i) Check kit aboard: Anchor / Paddle / Tow Line etc	Beware of rope / obstructions in the water	Return fuel tank to main fuel store			
j) Check bung is inserted in transom	m) Switch off engine when near persons in the water,	Lower engine only once inside RIB cage			
k) Prime fuel bulb until hard (several pumps needed)	unless you might drift into danger!	 Lock engine safe top & bottom both locks! 			
I) Do <u>NOT</u> start engine whilst ashore / prop out of water	Always think safety!	Lock RIB cage door			
VHF Radio	Support Responsibilities	Lastly			
Familiarise yourself with VHF before going afloat	Attend every capsize within 3 minutes	Please report any issues to OOD Thank you for your Support Cover			
Check Volume is turned up to min 20	Care of people before property				
Check Channel is set to "37A"	Look out for any other incidences on the water				
Your VHF Call Sign is "Club Support"	Advise OOD if conditions too severe for Support Crew				
(You are <u>NOT</u> a Safety Boat)	Consider reducing sailing area in severe conditions				
Check VHF handset transmits / receives OK with OOD	Record any advice given to OOD in OOD's log book				

• Keep min 50m away from fishermen (incl those ashore)

• Keep speed low when not necessary, be aware of wash

• VHF technique: "OOD, OOD, this is Club Support" etc

• Keep VHF conversation short and precise